


Capri ECU Programming Harness (Software with Vector. Software and Coding Parameter with AL-Flasher)

Pinning ECU_Capri B0-Sample TOP view

WK_SENSE	X1-12	49	38	X1-1		LR_Detection	X3-1	27	CAN3_H	X2-26	26	13	X2-13	CAN2_H
GPIO_1	X1-13	50	39	X1-2		ADIN_4	X3-2	28	CAN3_L	X2-25	25	12	X2-12	CAN2_L
ADIN_1	X1-14	51	40	X1-3	AGND	ADIN_3	X3-3	29		X2-24	24	11	X2-11	ADIN_2
AIN_6	X1-15	52	41	X1-4	AIN_1	AIN_11	X3-4	30	VCCX_3	X2-23	23	10	X2-10	LED1
AIN_5	X1-16	53	42	X1-5		AIN_8	X3-5	31	POS_IN	X2-22	22	9	X2-9	LED2
AIN_4	X1-17	54	43	X1-6	CAN1_H	AIN_7	X3-6	32		X2-21	21	8	X2-8	LED3
AIN_3	X1-18	55	44	X1-7	CAN1_L	VCCX_1	X3-7	33	DC_MOTOR_S	X2-20	20	7	X2-7	LED4
AIN_2	X1-19	56	45	X1-8	STP1_S2B	STP1_S1A	X3-8	34	DOUT2	X2-19	19	6	X2-6	LED5
	X1-20	57	46	X1-9	STP1_S1B	STP1_S2A	X3-9	35	DOUT1	X2-18	18	5	X2-5	LED6
	X1-21	58	47	X1-10	GND	GND	X3-10	36		X2-17	17	4	X2-4	LED7
	X1-22	59	48	X1-11	GND				HSS1	X2-16	16	3	X2-3	LED8
KL30	X1-23	60				GND	X3-11	37	HSS2	X2-15	15	2	X2-2	
									HSS3	X2-14	14	1	X2-1	

Capri connector



		Capri Harness
Author:	ALSH:Chenhui	Programming ECU
Last Edited:	18.02.2024	
Filename:	<Capri_ECU_Programming_Harness.vsd>	