


TSMaster What's New

2024-01-26


- [1] Improved: Window flickers when switch between MDI and Normal State
- [2] Improved: cyclic message added by API become more precise
- [3] New: Panel TPnl files can be directly dragged into TSMaster Interface
- [4] Improved: NOK results in NOP now generates error info in Graphic Program
- [5] Refactored: Graphics now accurately displays sporadic abnormal signal points within a vast number of signal points

Example: There are four abnormal signal points within 100000 normal signal points


points:



No matter how the graphic window is scaled, these four abnormal signals can always be displayed correctly.



[6] New: Panel API supports clear any panel control contents




[7] New APIs for form operation: show, hide, toggle MDI, set positions

[8] New Toolbox: GW2112 for TOSUN gateway devices

[9] New: Drag drop supported for system variables config file

[10] Bug fix: CAN Trace distinguish same identifier with standard and extended

[11] New: Graphics signal now supports arbitrary expressions



[12] New: create_form API added for UI automation

[13] Improved: Graphics grid now follows axis markers