

Getting Started with the SuperTrace Probe



Green Hills Software
30 West Sola Street
Santa Barbara, California 93101
USA
Tel: 805-965-6044
Fax: 805-965-6343
www.ghs.com

DISCLAIMER

GREEN HILLS SOFTWARE MAKES NO REPRESENTATIONS OR WARRANTIES WITH RESPECT TO THE CONTENTS HEREOF AND SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, Green Hills Software reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Green Hills Software to notify any person of such revision or changes.

Copyright © 1983-2013 by Green Hills Software. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without prior written permission from Green Hills Software.

Green Hills, the Green Hills logo, CodeBalance, GMART, GSTART, INTEGRITY, MULTI, and Slingshot are registered trademarks of Green Hills Software. AdaMULTI, Built with INTEGRITY, EventAnalyzer, G-Cover, GHnet, GHnetLite, Green Hills Probe, Integrate, ISIM, u-velOSity, PathAnalyzer, Quick Start, ResourceAnalyzer, Safety Critical Products, SuperTrace Probe, TimeMachine, TotalDeveloper, DoubleCheck, and velOSity are trademarks of Green Hills Software.

All other company, product, or service names mentioned in this book may be trademarks or service marks of their respective owners.

For a partial listing of Green Hills Software and periodically updated patent marking information, please visit http://www.ghs.com/copyright_patent.html.

PubID: supertrace_start-492848

Branch: <http://toolsvc/branches/probe-branch-5.0.4>

Date: August 12, 2013

Contents

1. Installing Your Probe	1
About This Book	2
Requirements	2
Terms You Should Know	2
When You Encounter Problems	3
Verifying Components	4
Installing SuperTrace Probe Software	5
Connecting Your Probe to Your Target	7
Connecting with TraceEverywhere	7
Connecting with HSST	9
Connecting Your Host to Your Probe Over the Serial Port	10
 2. Configuring Your Probe	 13
Connecting to Your Probe Over Ethernet	14
Configuring a Dynamic IP Address with DHCP	15
Configuring a Static IP Address	16
Testing Your Probe's Ethernet Connection	18
Connecting to Your Probe Over USB	20
Connecting the Probe Administrator to Your Probe	21
Detecting Your Target	22
Configuring Probe Options with a Configuration File	23
Running Diagnostics	24
 3. Creating and Debugging a Program	 27
Creating a Top Project for Your Program	28
Top Project Structure	31
Building a Program from the Top Project	32
Connecting MULTI to Your Target	33
Downloading and Debugging a Program	35

Viewing the 'Hello World' Program's Trace Data 36

A. Troubleshooting 37

Setting Up Your Hardware 38

 Connecting with a Legacy Trace Pod 39

 The Supplied Ribbon Cable or Pod Does Not Fit in the
 Target's JTAG Header 40

 The SuperTrace Probe v3 Power Light Is Solid Red 40

 The SuperTrace Probe v3 Parallel or Serial Light Is Solid
 Red 40

 Corrupted Data is Printed to the Serial Terminal 40

 Cannot Type Commands Into the Serial Terminal 41

 SuperTrace Probe v3 Beeps in a Repeating Pattern 41

Configuring Your Probe to Connect to MULTI 43

 Cannot Find Telnet On Windows Vista 43

 Cannot Connect to Probe Over Telnet 43

 Cannot Connect to Probe Over USB 45

 Windows is Unable to Start Probe as a USB Device 45

Configuring Your Probe for Your Target 46

 detect Issues Error 60 46

 detect Does Not Display a Processor Table 47

 detect Issues Error 71 47

 detect Sets the Target Processors and then Issues an
 Error 48

 detect Sets the Target Processor to other 48

 detect Sets the Target Processor Incorrectly 48

 detect Passes but vb Fails 49

 tr Does Not Reset the Target 49

 vr Fails or Issues Error 18 50

 MULTI Reports a 'Traceserv Failed to Respond' Error 50

 The Trace List Is Empty, Near Empty, or Reports an
 Error 50

General Configuration Instructions 52

 Diagnosing Low-Level JTAG Connection Problems 52

 Configuring the Probe's Logic High Level 54

 Enabling Your Target's Trace Port 54

 Recovering that Does Not Boot Properly 55

Uninstalling Probe Software	56
Index	57

Chapter 1

Installing Your Probe

Contents

About This Book	2
Requirements	2
Terms You Should Know	2
When You Encounter Problems	3
Verifying Components	4
Installing SuperTrace Probe Software	5
Connecting Your Probe to Your Target	7
Connecting Your Host to Your Probe Over the Serial Port	10

About This Book

This book explains how to install and configure your probe. You will learn how to:

- Connect your probe to your hardware and host machine
- Configure your probe for use with your hardware and MULTI
- Create and build a project for an example program
- Download the program to your hardware and debug it
- View trace data from your hardware

For reference information, detailed information about commands and options, and advanced topics, see the *Green Hills Debug Probes User's Guide*.

Requirements

Before installing and configuring your SuperTrace Probe, you must install MULTI and the Green Hills Compiler for each architecture that you plan to use. If you have not installed MULTI yet, do so now. For information about installing MULTI, see the installation document located in the root directory of the installation CD. The instructions in this guide cover installation with MULTI 6. If you are using another version, some instructions may differ.

Terms You Should Know

- **Host** — The computer on which you are running MULTI.
- **Target** — The hardware for which you are developing programs.
- **Target Adapter** — An adapter that connects your probe to your target. Target adapters can connect both debug and trace signals to a debug probe, and are used by both Green Hills Probe and SuperTrace Probe.
- **Trace Pod** — A target adapter with active logic that collects trace data and connects the port marked `PARALLEL` on the SuperTrace Probe to your target's trace port. A Trace Pod also connects to the

debug signals of a target, and allows the SuperTrace Probe to control and debug a target. There are two kinds of Trace Pods: the TraceEverywhere (TE) Trace Pod and an older Legacy Trace Pod. This manual mostly refers to the TE Trace Pod.

- **TraceEverywhere (TE)** — The Green Hills interface for trace port adapters that carry trace and debugging signals. TE trace adapters adapt a specific target trace port to TE so that the SuperTrace Probe can trace different targets by just changing the TE trace adapter. The Green Hills Probe also uses TE trace adapters to connect to various debugging ports, such as Nexus, ARM CoreSight, and other JTAG-based ports.
- **High-Speed Serial Trace (HSST)** — Trace using a high-speed serial protocol such as Aurora, which requires a SuperTrace Probe with a port in front marked `SERIAL`. Because of HSST's high-speed signaling, SuperTrace Probe uses a target-specific cable plugged directly into the probe with no TE adapters. HSST often includes a target's regular debug signals allowing the SuperTrace Probe to control and debug a target through a single cable.
- **TE Trace Kit** — A target connection kit that consists of a pre-attached cable and trace pod, and a TE target adapter.
- **HSST Kit** — A cable that connects your probe directly to your target for HSST (no adapters or pods required).
- **Legacy Kit** — A target connection kit that consists of a pre-attached cable and trace pod, and may or may not contain an additional adapter for your target.

When You Encounter Problems


If at any time you receive an error or are unable to continue, see Appendix A, “Troubleshooting” on page 37. For more information about any of the options or procedures described in this book, see the *Green Hills Debug Probes User's Guide*.

Verifying Components

All SuperTrace Probe boxes contain the following items:




SuperTrace Probe




Power supply




SuperTrace Probe CD



Ethernet cable




USB cable



Null modem serial cable


Depending on your target connection, it will also contain one of the following kits:

TraceEverywhere (TE) Kit




TE pod

HSST Kit




HSST cable

Legacy Kit




legacy trace pod




Extension

TE Kits come with an adapter (varies by target):



Edge mount adapter



Vertical mount adapter

Installing SuperTrace Probe Software

Before using your SuperTrace Probe with MULTI, you must install the software on the SuperTrace Probe CD. The software on the CD includes:

- USB drivers (Windows only).
- Probe firmware for the release marked on the CD. This firmware is installed in ***install_directory/ghprobe***.
- **Project Wizard** files that add support for new boards.
- Documentation, as PDF files and in the MULTI help viewer.

To install the software, follow the instructions provided for your operating system:

Windows

1. Log in to Windows using an account with administrative privileges. Close MULTI and any other Green Hills Software applications. Make sure that the probe is not connected to your host machine.
2. Insert the SuperTrace Probe CD for your target into the CD-ROM drive of your host machine. If the installation program does not start automatically, run ***ginstall_win32.exe***.
3. When prompted for an installation directory, specify the directory where the Green Hills Compiler is installed (for example, ***c:\ghs\comp201254***). If you are using MULTI 5 or older, specify the directory where MULTI is installed.

Linux or Solaris

1. Close MULTI and any other Green Hills Software applications.
2. Insert the SuperTrace Probe CD for your target into the CD-ROM drive of your host machine. If the installation program does not start automatically, run one of the following programs, depending on your operating system:
 - ***ginstall_solaris2***
 - ***ginstall_linux86***

3. When prompted for an installation directory, specify the directory the Green Hills Compiler is installed (for example, **/ghs/comp201254**). If you are using MULTI 5 or older, specify the directory where MULTI is installed.

Connecting Your Probe to Your Target


After checking the contents of the box and installing the necessary software, you are ready to set up your SuperTrace Probe. This section explains how to connect the probe to your target using current cabling systems.

All SuperTrace Probes ship with a **PARALLEL** port. SuperTrace Probes that support high-speed serial trace (HSST) have an additional **SERIAL** port on the front. Depending on the kind of connection you need to make and the cabling system you are using, skip to one of the following sections:


- “Connecting with TraceEverywhere” on page 7
- “Connecting with a Legacy Trace Pod” on page 39
- “Connecting with HSST” on page 9 (requires a probe with a **SERIAL** port on the front)

Connecting with TraceEverywhere

1. Make sure that the power switch on the back of the probe is in the off (○) position.
2. Connect the TE trace pod to your TE adapter:




3. Connect the probe end of the cable to the **PARALLEL** port on the front of the probe. The connector is keyed and only fits in one way. Do not force the cable.



4. Make sure that your target's power is off, and connect the trace pod to your target. If your target has a shrouded MICTOR connector, remove the shroud before connecting the pod to your target.
5. If we included a MICTOR extension cable with your shipment, we recommend that you use it for the following reasons:
 - It reduces strain on connections.
 - It is helpful for making connections in tight areas.
 - It may improve trace reliability on some targets.
6. Connect the power supply to the power input connector on the back of the probe and to an AC power outlet.
7. Turn the power switch on the back of the probe to the on (I) position. The **Parallel** light should turn green. If it does not, see Appendix A, “Troubleshooting” on page 37.

Connecting with HSST

1. Make sure that the power switch on the back of the probe is in the off (○) position.
2. Connect the probe end of the cable to the **SERIAL** port on the front of the probe (not the RS-232 port on the back), and secure it by tightening the large screws on the cable housing. Do not force the cable:




3. Make sure that your target's power is off, and connect the other end of the cable to your target.
4. Connect the power supply to the power input connector on the back of the probe and to an AC power outlet.
5. Turn the power switch on the back of the probe to the on (|) position. The **Serial** light should turn green. If it does not, see Appendix A, "Troubleshooting" on page 37.

Connecting Your Host to Your Probe Over the Serial Port

Now that you have connected your probe to your target, you can connect to the probe from your host machine over an RS-232 serial connection to confirm that it is operational. To establish a serial connection:

1. Connect a null modem cable to the serial port on the back of your probe and to a serial port on your host PC:



2. On your host machine, open a connection to your serial port with a serial terminal emulator (such as TeraTerm) using the following settings:
 - **Baud Rate** — 9600
 - **Data Bits** — 8
 - **Parity** — none
 - **Stop Bits** — 1
 - **Flow Control** — none
3. Set the probe's power switch to the on position (|).
4. If you see the following banner in the serial terminal, the serial connection was successful (the banner may vary depending on your firmware revision):

```
ghBootloader
Green Hills Probe, Version 3
Unit Serial Number 100111
Booting...Reading Configuration from non-volatile memory.

Probe Firmware Release Version 4.4.2

Module core built Tue Jul 10 17:54:47 2012
Serial No: 100111
SuperTrace Probe v3
Part number 520-ST400-01x
```

Green Hills Software, Inc
<http://www.ghs.com>

```
Serial:      9600
USB:         Enabled
Ethernet:    Enabled
IP:          DHCP
Gateway:     DHCP
Netmask:     DHCP
MAC Addr:    00:11:22:33:44:ee
```

```
Starting the initialization sequence.
01234567 done.
```

```
Type 'info' to list probe information.
Type 'setup' to set the current configuration.
Type 'help' to list the online help.
```

```
ppc5567[0,..] %
```

The prompt after the banner indicates that booting has finished, and displays both the target setting and state (ppc5567 is provided as an example).



Note

You may power on your target after it is plugged into to the probe and the probe is turned on, but you do not need to do so until you are ready to communicate with it.

Chapter 2

Configuring Your Probe

Contents

- Connecting to Your Probe Over Ethernet 14
- Connecting to Your Probe Over USB 20
- Connecting the Probe Administrator to Your Probe 21
- Detecting Your Target 22
- Configuring Probe Options with a Configuration File 23
- Running Diagnostics 24

Your Green Hills probe is equipped with gigabit Ethernet and USB 2.0 ports for high-speed connections to your host computer. Although connecting to your probe through the serial port is a good way to confirm that it is operational, you must connect to your probe over Ethernet or USB to use it with MULTI.

- If you want to connect to your probe over Ethernet, see “Connecting to Your Probe Over Ethernet” on page 14
- If you want to connect to your probe over USB, see “Connecting to Your Probe Over USB” on page 20


Connecting to Your Probe Over Ethernet

The probe can detect network settings automatically using DHCP. To connect your probe to a network using this feature, see “Configuring a Dynamic IP Address with DHCP” on page 15.

If your network does not support DHCP or you want your probe to use a static IP address, you can configure the settings manually using the instructions in “Configuring a Static IP Address” on page 16.

Configuring a Dynamic IP Address with DHCP

In the serial terminal window, type `setup net`. The probe presents the following settings with their default values.



```
[?] % setup net
Green Hills Probe (tm) Interactive Setup

To accept the current setting press 'Enter'.
For information on any option type a '?'.
Use the 'set' command at a terminal to individually set options.

Network configuration (net):

  dhcp: [on]
  dhcp_lease: [0 days]
  hostname: [ghprobe18165]

Saving options to EEPROM...
[?] %
```

1. `dhcp` — Press Enter to accept the default setting (`on`).
2. `dhcp_lease` — Press Enter to accept the default setting. This setting specifies number of days that the probe retains its DHCP settings. The default is 0, meaning that the network settings never expire.
3. `hostname` — Type the hostname for your probe and press Enter. The DHCP server associates this hostname with your probe so that you can connect to your probe by specifying its hostname instead of its IP address. By default, the probe's hostname is `ghprobeserial`, where *serial* is your probe's serial number (for example, `ghprobe1234`). The probe's serial number is located on a sticker affixed to the bottom of the probe.

You have now configured your probe to obtain an IP address using DHCP. Skip to “Testing Your Probe's Ethernet Connection” on page 18.


Configuring a Static IP Address

If you want to configure your probe to have a static IP address, you might need to contact your network administrator to obtain the following settings:

- IP address
- Gateway
- Network mask

If you set the IP address incorrectly, you could disrupt other devices on your network.

In the serial terminal window, type `setup net`. The probe presents the following settings with their default values.



```
Tera Term Web 3.1 - COM1 VT
File Edit Setup Web Control Window Help

[?] % setup net
Green Hills Probe (tm) Interactive Setup

  To accept the current setting press 'Enter'.
  For information on any option type a '?'.
  Use the 'set' command at a terminal to individually set options.

Network configuration (net):

  dhcp: [on] off
NOTE: You must now set a static IP.  If no IP is set, DHCP will be re-enabled
on next boot.
  ip: [0.0.0.0] 192.168.1.150
NOTE: You have to reboot for this option to take effect.
  netmask: [255.255.255.0]
  gateway: [0.0.0.0] 192.168.1.1
NOTE: You have to reboot for this option to take effect.
  hostname: [ghprobe18165]

Saving options to EEPROM...

Options have been changed that require the probe to be rebooted before taking
effect:

  Reboot now [yes]

Rebooting probe...
```


1. `dhcp` — Type `off` and press Enter.
2. `ip` — Type an IP address in dotted quad form and press Enter (for example, `192.168.1.150`).
3. `netmask` — Type the network mask in dotted quad form and press Enter. The default setting is appropriate for class C networks, because most networks are class C. Use a different setting if you are not on a class C network.
4. `gateway` — Type the gateway's IP address in dotted quad form and press Enter.
5. `hostname` — Press enter to accept the default setting. This setting is not used when DHCP is off; it is provided for future protocol support. When transporting your probe between networks with and without DHCP, your probe retains its hostname.
6. When the probe asks if you want to reboot, press Enter to reboot the probe.

You have now configured your probe to use a static IP address.

Testing Your Probe's Ethernet Connection


After configuring your probe for your network, test the Ethernet connection with Telnet. To connect to the probe through Telnet:

1. Plug one end of an Ethernet cable into your probe and the other end into a switch or hub that is attached to your network. If the probe detects that it is connected to a network, the Ethernet link status light turns on:



2. In the serial terminal window, type `reboot` to reboot your probe.
3. After your probe reboots, type `set ip` to confirm that your probe has an IP address.
4. If you are using Windows, select **Run** from the **Start** menu, type `telnet`, and click **OK**. If you are using Linux, open a shell and type `telnet`.

5. At the Telnet prompt, type `open ip_address`, where *ip_address* is your probe's IP address. If Telnet can connect to the probe, you should see the following screen:



```
Telnet ghsprobe100010

Probe Firmware Release Version 4.2.0
Module core built Fri Jul  8 17:31:30 2011
Serial No: 100010
SuperTrace Probe v3
Part number 520-ST400-01x
Green Hills Software, Inc
http://www.ghs.com

Type 'info' to list probe information.
Type 'setup' to set the current configuration.
Type 'help' to list the online help.

ppc5567I0.E1 %
```



Note


If you are using DHCP and your network supports dynamic hostnames, you can also open a connection with `open hostname`, where *hostname* is your probe's hostname.

You can now connect to your probe over Ethernet. Continue to “Connecting the Probe Administrator to Your Probe” on page 21.

Connecting to Your Probe Over USB

This section explains how to connect your probe to your host machine over USB. USB connections are supported on Windows only.

1. Connect a USB cable to the USB connector on the back of your probe and to a USB port on your host machine (or a USB hub connected to your host machine). The USB link status light should turn on:



2. If Windows reports that it has found a new USB device and asks to search for the appropriate drivers, click **Yes**. Windows will locate and use the driver you installed from the SuperTrace Probe CD.



Note


If Windows cannot find the driver and the **Install New Hardware Wizard** appears, run the installer on the SuperTrace Probe CD. For more information, see “Installing SuperTrace Probe Software” on page 5.

Connecting the Probe Administrator to Your Probe

Now that the probe can connect to MULTI, you can use MULTI's **Probe Administrator** to configure the probe for your target. The **Probe Administrator** is a program that lists all available probes and allows you to perform basic tasks such as setting options and updating firmware.

To connect to the **Probe Administrator**:

1. On your host machine, run MULTI.
2. In the MULTI Launcher, select **Utilities** → **Probe Administrator**.
3. In the **Probe Administrator**, select **File** → **New Probe** to open the **New Probe** dialog box.



4. In the **Probe Name** box, type a name for your probe that is easy to remember. This name is for your convenience only and is unrelated to the probe's hostname.
5. If you connected to your probe over USB, select the **USB** radio button. If you connected to your probe over Ethernet, select the **Ethernet** radio button and type your probe's IP address in the **IP Address** box.
6. Click **OK**.
7. In the **Probe Administrator**, double-click your probe's name to open a **Probe Administration** window. You are now connected to your probe with the **Probe Administrator**.

Detecting Your Target

The **Probe Administrator** contains a prompt that you can use to send commands to your probe. To use this prompt to configure your probe for your target board:

1. Power on your target.
2. In the **Probe Administration** window, click the **Prompt** tab.
3. At the prompt, type `detect`. This command configures the SuperTrace Probe for the processors on your target board. It is useful even if the prompt indicates that the probe knows what target you are using, because it confirms that the probe is able to see your target and that the target is configured correctly. If the command prints the following message:

`Target has been detected and set to target_string`

where *target_string* is the name of your target, the detection was successful.

4. Type `save` to save the settings changed by **detect**.

If you have problems detecting your processors, see Appendix A, “Troubleshooting” on page 37.

Configuring Probe Options with a Configuration File

Green Hills provides probe configuration files for many different target boards. These files contain tested settings for all target-related configuration options. To determine if one of these files exists for your board, and to use that file to configure your probe:

1. In a terminal window or command prompt, navigate to your MULTI install directory for MULTI 5, or your tools install directory for MULTI 6 or newer. Inside that directory, navigate to **target\architecture**.
2. If there is a directory that is named after your board, navigate to that directory and look for a file that ends in **.cfg** or **.ghpcfg**. When you find the file, run one of the following commands:

```
> tools_install\mpadmin -cfgload hostname config_file  
> tools_install\mpadmin -cfgload -usb config_file
```

If there is no directory named after your board, or if the directory exists but it does not contain a configuration file, continue to the next section.

Running Diagnostics

Now that you have detected your target, run the following diagnostics to make sure that you can communicate with it:

1. Type `vle` to verify that the connection from the probe to the trace pod is functioning properly. If it is, this command does not print anything. If there are problems, it prints an error.
2. Type `vb` to tests the bypass register of all devices on the JTAG scan chain. `vb` is not applicable for PowerPC 5xx, PowerPC 8xx and ColdFire targets. If you are using one of those targets, skip this step.
3. If your target has multiple cores, type `tl` (as in “target list”) to obtain a list of cores and IDs. Then, type `t core_id` to select a core. Most subsequent commands, including the following diagnostics, control or configure just that core.
4. Type `tr` to reset your target. This command verifies that you can reset your target, and is necessary for some targets after testing bypass mode.
5. Type `rr` to confirm that the probe can read your target's registers. When successful, this command returns a list of registers, similar to the following output:

```
ppc5200[H] % rr
gpr0=0xac5658ad gpr9=0x805000a0 gpr18=0x244444889 gpr27=0x04100821
gpr1=0x845008a1 gpr10=0x04400880 gpr19=0x8816102c gpr28=0x0446088c
gpr2=0x08421084 gpr11=0x04000801 gpr20=0x2c5058a0 gpr29=0x08101021
gpr3=0x24004800 gpr12=0x04020804 gpr21=0xa0404080 gpr30=0x2c425885
gpr4=0x8c001800 gpr13=0x08001001 gpr22=0x8c041808 gpr31=0xa0024005
gpr5=0x28005000 gpr14=0x2006400d gpr23=0x24144829 lr=0x00000000
gpr6=0xa0044008 gpr15=0x80120024 gpr24=0x885610ad iar=0x00003ffc
gpr7=0x88141029 gpr16=0x00440089 gpr25=0x205240a4
gpr8=0x205640ac gpr17=0x08121024 gpr26=0x84440888
ppc5200[H] %
```

6. Type `vr 100` to test the probe's ability to write to registers and read back the values. This command runs the test 100 times.
7. Close the **Probe Administration** window. If you leave the window open, other applications may not be able to connect to your probe over USB.

If you are able to run all of the above commands without errors, your probe is able to communicate with your target and is ready for use with the MULTI Debugger. If any of the diagnostics fail, see Appendix A, “Troubleshooting” on page 37.

Chapter 3

Creating and Debugging a Program

Contents

Creating a Top Project for Your Program 28

Top Project Structure 31

Building a Program from the Top Project 32

Connecting MULTI to Your Target 33

Downloading and Debugging a Program 35

Viewing the 'Hello World' Program's Trace Data 36

Before beginning your first MULTI debugging session using your SuperTrace Probe, you must ensure that your target board is configured properly. This section explains how to create a Top Project that you can use to configure your target, test your debugging environment, and download and debug a “Hello World” program.


Creating a Top Project for Your Program

The **Project Wizard** is a tool that prompts you for information about your target board and creates a Top Project that contains:


- Connection Methods that you use to connect to your target through your SuperTrace Probe.
- A MULTI board setup (**.mbs**) script that configures your target.
- Linker directives files that define memory maps for your target.

To use the **Project Wizard** to create a **Top Project**:


1. On your host machine, open MULTI.
2. From the MULTI Launcher, click  and select **Create Project** to open the **Project Wizard**.
3. Leave the default value in the **Name** box, and enter a directory for your Top Project in the **Directory** box. Click the **Next** button.




4. In the **Operating System** list, select **Stand-Alone**. Click the **Next** button.



5. In the **Processor Family** list, select the processor family to which your target's processor belongs. If you have only installed one processor family for MULTI, the wizard does not display this screen. Click the **Next** button.



6. In the **Target Board** list, select your target board. If your target board is not listed or you are using custom hardware, click the plus sign to the left of the **Generic** item at the top of the list and select your processor. In this case, you will probably need to customize the board setup script and linker directives files the wizard creates for your target. Click the **Finish** button to create your Top Project.




7. When the **Project Wizard** closes, a dialog box may open to inform you about the newly created Top Project. If so, click the **OK** button to continue.
8. After you create a new Top Project, the **Add Item to Project** dialog box opens. If you are creating a Stand-Alone project, select **Hello World (C)** and click the **Finish** button. This adds an example “Hello World” project to your Top Project.

You have now created a Top Project for your target.

For more information about **Project Wizard** screens and options, see the documentation about creating a new project in the *MULTI: Building Applications* book for your processor family.

Top Project Structure

After you create a Top Project, the MULTI Project Manager opens. It should look similar to the following window:



There are three projects in the window:

- **dir\default.gpj** — The Top Project.
- **src_hello\hello.gpj** — The example “Hello World” project you added with the **Add Item to Project** dialog box.
- **tgt\resources.gpj** — The *Target Resources project*. This project contains files necessary to configure and connect to your target (such as setup scripts and linker directives files).
 - **mpserv_standard.mbs** — The board setup script for your target. This script prepares your target for downloading and running a program. You may need to customize this script if you are using custom hardware.
 - **name.ld** — Linker directives files for your target. These files help determine how your program is laid out in memory. You may need to customize these files if you are using custom hardware.

In this example, the **src_hello\hello.gpj** project is linked using **standalone_ram.ld**. The **tgt\standalone_ram.ld** item in the **src_hello\hello.gpj** project represents the same file as the **standalone_ram.ld** item in the Target Resources project.

- **board_info.txt** (not available for all targets) — Additional notes about your target. If your project contains this file, read its contents before proceeding to the next section.

Building a Program from the Top Project

After you create a Top Project with the **Project Wizard**, you should test your debugging environment by downloading and running the example “Hello World” program. Before downloading the program, you must build your project.

To build the “Hello World” example project:

1. Select **src_hello\hello.gpj** in the Project Manager.
2. Click .


If the build was successful, you should see text similar to the following in the **Status** pane:

```
Building hello
Compiling hello.c because hello.o does not exist
Linking hello because it does not exist
Done
Build successful (Mon Jul 25 12:30:00 2011)
```


Connecting MULTI to Your Target

To connect MULTI to your target:

1. Verify that all hardware connections are tight and secure, and that both the board and your probe are powered.
2. In the Project Manager, select **src_hello\hello.gpj** and click  to open the MULTI Debugger.
3. In the Debugger window, click  to open a **Connection Chooser** window.
4. In the **Connect to a Target** list, select the **Green Hills Debug Probe (mpserv)** connection for your target. For example:



5. Click the **Connect** button. When the **Connection Chooser** prompts you to enter a Probe Name for the new connection, click **OK**. The **Connection Editor** window opens.



6. In the **Connection Editor** window:
 - a. In the **Connection** tab, select the radio button that corresponds to your connection type (Ethernet or USB). If you connect to your probe over Ethernet, type the probe's hostname or IP address in the **Probe Name or IP Address** box. If you connect to multiple probes over USB, type the probe's serial number in the **Probe Serial Number or USB Index** box to specify which probe you want to connect to, and make sure that there are no active connections to that probe (such as the **Probe Administrator**).
 - b. In the **Target Setup script** box, leave the default value (**mpserv_standard.mbs**). This file is the setup script that the **Project Wizard** generated and placed in your Target Resources project.
 - c. Click **OK**.

The MULTI Debugger is now connected to your target.

For more information about the **Connection Editor**, see the documentation about the Connection Editor in the *MULTI: Configuring Connections* book.



Warning

Do not unplug the USB cable while MULTI is connected to your target over USB.

Downloading and Debugging a Program

To download and run the “Hello World” program:

1. In the MULTI Debugger, click . The **Prepare Target** dialog box opens.
2. In the **Prepare Target** dialog box, leave the settings at their default values. The project is configured to download the program to RAM. Click **OK**.
3. The **Initializing Target** dialog box opens. This dialog box shows progress as MULTI runs your setup script and downloads the program. It closes when the progress is complete.

If the download and execution of the program are successful, your debugger should show output similar to the following:

```
I/O: Hello world.
I/O: -----
```

If the download was not successful, the **Prepare Target** dialog opens and displays any errors that occurred during the setup script or while downloading the program. If you are using custom hardware and have not modified the default setup script and/or linker directives files, you should expect some errors in red text in the **Prepare Target** dialog box.


If this happens, you must modify the default setup script and linker directives files in your Target Resources project to configure your target properly. For more information, see Chapter 2, “Configuring Target Resources” in the *Green Hills Debug Probes User's Guide*.

Viewing the 'Hello World' Program's Trace Data

By default, the SuperTrace Probe collects trace data every time it halts your target. This means that you can view trace data immediately after the 'Hello World' program terminates. To view the trace data in list form:

- In the Debugger, select **TimeMachine** → **Trace List**

If the **Trace List** opens and looks similar to the following screen, your trace connection is configured properly:



For more information about browsing trace data, see the documentation about analyzing trace data with the TimeMachine tool suite in the *MULTI: Debugging* book.

Troubleshooting

Contents

Setting Up Your Hardware 38

Configuring Your Probe to Connect to MULTI 43

Configuring Your Probe for Your Target 46

General Configuration Instructions 52

Uninstalling Probe Software 56

This section explains how to troubleshoot problems you may encounter when configuring your probe to detect and communicate with your target. Before looking at a specific topic, make sure that:

- Your target is powered on.
- Your probe is powered on.
- All connections are tight and secure.
- The supplied ribbon cable is plugged into your target in the proper orientation, in the correct port. Also, check that it is properly aligned (not shifted over by one pin).



Note

On shielded COP cables, the red stripe on the cable indicates pin 16, not pin 1.

If you have checked all the items in the previous list and are still having trouble setting up your SuperTrace Probe, consult one of the following sections.

Setting Up Your Hardware


This section provides troubleshooting steps for initial probe setup.

- “Connecting with a Legacy Trace Pod” on page 39
- “The Supplied Ribbon Cable or Pod Does Not Fit in the Target's JTAG Header” on page 40
- “The SuperTrace Probe v3 Power Light Is Solid Red” on page 40
- “The SuperTrace Probe v3 Parallel or Serial Light Is Solid Red” on page 40
- “Corrupted Data is Printed to the Serial Terminal” on page 40
- “Cannot Type Commands Into the Serial Terminal” on page 41
- “SuperTrace Probe v3 Beeps in a Repeating Pattern” on page 41

Connecting with a Legacy Trace Pod

The instructions in this guide cover connections over TE and HSST. This section describes how to connect your probe to your target using a legacy trace pod:

1. Make sure that your probe's power is off.
2. Connect the probe end of the cable to the **PARALLEL** port on the front of the probe.
3. Check that the target adapter is appropriate for your target and connect the legacy trace pod to the adapter. For example:



4. Make sure your target's power is off, and connect the other end of the cable to your target. If your target has a shrouded MICTOR connector, remove the shroud before connecting the kit to your target.



Warning

If you have a Nexus target, verify that your target adapter is labeled “Nexus” and make sure to attach it before connecting the trace pod to your target, or you may damage the trace pod.

5. If we included a MICTOR extension cable with your shipment, we recommend that you use it for the following reasons:
 - It reduces strain on connections.
 - It is helpful for making connections in tight areas.
 - It may improve trace reliability on some targets.

The Supplied Ribbon Cable or Pod Does Not Fit in the Target's JTAG Header

If the supplied ribbon cable or pod does not fit in one of your target's JTAG ports:

- Do not attempt to physically modify the cable or pod.
- Some targets have more than one JTAG header. Look for a different JTAG header that fits.
- If your SuperTrace Probe shipped with adapters for the ribbon cable or pod, try using one of them.
- If you are using a trace pod adapter, MICTOR pin-swapping adapter, or MICTOR extension cord, and your target has a shrouded MICTOR connector, remove the shroud.

The SuperTrace Probe v3 Power Light Is Solid Red

If the power light on your SuperTrace Probe v3 is solid red, there is an electrical problem. See “SuperTrace Probe v3 Beeps in a Repeating Pattern” on page 41.

The SuperTrace Probe v3 Parallel or Serial Light Is Solid Red

If the **parallel** or **serial** light on your SuperTrace Probe v3 is red:

- Make sure that the trace pod and cable are plugged in all the way.
- Make sure that either a High-Speed Serial Trace or a parallel cable is connected, but not both.
- If the connections are secure but the red light persists, contact Green Hills support.

Corrupted Data is Printed to the Serial Terminal

If your serial terminal emulator is displaying corrupted data when connected to the probe, your terminal's baud rate is probably incorrect.

The probe's serial port is configured at 9600 baud for a few seconds after it is power cycled, after which it changes to its configured baud rate

setting. If the configured setting is not 9600 baud, the probe prints the following message in the terminal before changing the baud rate. For example, if the probe's baud rate is set to 38400, it would print the following message:

```
Switching baud rate to 38400, press the space bar to remain  
at 9600.
```

If you need to change the rate back to 9600 baud:

1. Press the space bar when the probe prints this message.
2. After you are connected to the probe, type:

```
set baud 9600
```

If you want to continue using the new baud rate (for example, 38400 baud), change the baud rate setting in your terminal program to 38400.

Cannot Type Commands Into the Serial Terminal

If you cannot type commands into the serial terminal:

- Make sure serial flow control is turned off in your serial terminal.
- Use a different null modem serial cable.



Note

Certain versions of the HyperTerminal application exhibit problems communicating with target systems in general. If you are experiencing problems, restart HyperTerminal. If this does not remedy the problem, try a different host machine, upgrade HyperTerminal, or switch to a different application.

SuperTrace Probe v3 Beeps in a Repeating Pattern

If your SuperTrace Probe v3 beeps in a repeating pattern, it indicates one of the following conditions:

- three short beeps — The probe has a blown fuse. Turn off the probe and contact Green Hills support.

- three short beeps followed by a long beep — The power supply voltage is inadequate. The probe requires a power supply that provides 12 V and 4 Amps.
- a high beep followed by a low beep — The probe is overheating. If this happens:
 - Turn the probe off immediately.
 - Check to see if any of the probe's vents are obstructed. If they are, remove the obstruction before turning the probe on again.
 - Check the ambient temperature near the probe and make sure it is below 120 F (50 C).

If none of the vents are obstructed and the ambient temperature is within operating levels, call Green Hills support.

Configuring Your Probe to Connect to MULTI

This section provides troubleshooting steps for configuring your probe to connect to your host machine.

- “Cannot Find Telnet On Windows Vista” on page 43
- “Cannot Connect to Probe Over Telnet” on page 43
- “Cannot Connect to Probe Over USB” on page 45
- “Windows is Unable to Start Probe as a USB Device” on page 45

Cannot Find Telnet On Windows Vista

The Telnet application is not installed by default on Windows Vista systems. To install the Telnet application:

1. Click the **Start** button and click **Control Panel**.
2. In the control panel, click **Programs**. In the **Programs and Features** group, click **Turn Windows Features On or Off**. If you are using classic view, double-click **Programs and Features**, then click **Turn Windows Features On or Off** in the **Tasks** list.
3. Select the **Telnet Client** check box and click **OK**.

Cannot Connect to Probe Over Telnet

If you cannot connect to your SuperTrace Probe over Telnet, your Ethernet settings are probably incorrect. The easiest way to determine if your probe Ethernet settings are correct is to ping it from your host machine. To ping your probe, from a command prompt, type:

```
$ ping hostname
```

where *hostname* is your probe's hostname, or

```
$ ping ip_address
```

where *ip_address* is your probe's IP address.

If **ping** is successful, it prints a report similar to the following:

```
$ ping ghprobe11111

Pinging ghprobe11111.ghs.com [192.168.100.111] with 32 bytes of data:

Reply from 192.168.100.111: bytes=32 time<10ms TTL=29
Reply from 192.168.100.111: bytes=32 time=10ms TTL=29
Reply from 192.168.100.111: bytes=32 time<10ms TTL=29
Reply from 192.168.100.111: bytes=32 time<10ms TTL=29

Ping statistics for 192.168.100.111:
    Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 10ms, Average = 2ms
```

If **ping** is unsuccessful, it prints a report similar to the following:

```
$ ping ghprobe11111

Pinging ghprobe11111.ghs.com [192.168.100.111] with 32 bytes of data:

Request timed out.
Request timed out.
Request timed out.
Request timed out.

Ping statistics for 192.168.100.111:
    Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms
```

- If **ping** is unsuccessful, verify that an Ethernet cable is plugged in and that the green connection light in the upper-right corner of the probe's Ethernet port is illuminated.
 - If it is illuminated, watch the light in the upper-left corner of the Ethernet port. On beige probes this light is orange, and on black probes it is green. If the light on the left is not flashing periodically, you may need to reconfigure your IP address, netmask, and/or gateway (see “Connecting to Your Probe Over Ethernet” on page 14 for instructions).
 - If it is not illuminated, try a different cable or connect to a different port on your hub or switch.
- If **ping** is successful but you cannot connect to the probe over Telnet, unplug the Ethernet cable from the probe and ping it again, with the cable unattached.
 - If **ping** is still successful, another device on your network probably has the same hostname or IP address as your probe.

Obtain a unique address and hostname from your network administrator and reconfigure the probe (see “Connecting to Your Probe Over Ethernet” on page 14 for instructions).

- If **ping** is no longer successful, or if you have a unique IP address and still have problems, open a Telnet connection from a different host machine. If the problem still persists, contact Green Hills technical support.

Cannot Connect to Probe Over USB

USB is only supported on Windows.

Only one software program can connect to a probe over USB at a time. If you have connected to the probe over USB before, but now are unable to, check that there are no other active USB connections to the probe, such as **mpadmin**, **gpadmin**, **mpserv**, or the **Probe Administrator**. If there are, close them.

The USB link LED should illuminate when the host machine and the probe have both been booted. If this does not happen:

1. Check that you have properly installed the USB cable between your host machine and the probe.
2. If the previous steps do not solve the problem, unplug the USB cable from the probe and plug it back in again.
3. If the LED still does not illuminate, unplug the USB cable from the probe, re-install the drivers by running the installation application **setup.exe**, and then reattach the USB cable.
4. If the problem persists, contact Green Hills technical support.

Windows is Unable to Start Probe as a USB Device

On some hosts, Windows may report that it is unable to start your device (with error 10) the first time you plug in a probe to the USB port. If this happens, unplug the USB cable and plug it back in. Windows should now be able to start it as a USB device.

Configuring Your Probe for Your Target

This section provides troubleshooting steps for configuring your probe to connect to your target, detect its processors, and read registers. To follow the instructions in this section, your probe must be connected to your target, and your host must be connected to the probe over the serial port. For instructions that explain how to connect to your probe, see “Connecting Your Host to Your Probe Over the Serial Port” on page 10.

If the troubleshooting steps in this section do not address your problem, your target may require extra configuration. For more information, see “Usage Notes” in Appendix D, “Troubleshooting and Usage Notes” in the *Green Hills Debug Probes User's Guide*.

- “detect Issues Error 60” on page 46
- “detect Does Not Display a Processor Table” on page 47
- “detect Issues Error 71” on page 47
- “detect Sets the Target Processors and then Issues an Error” on page 48
- “detect Sets the Target Processor to other” on page 48
- “detect Sets the Target Processor Incorrectly” on page 48
- “detect Passes but vb Fails” on page 49
- “tr Does Not Reset the Target” on page 49
- “vr Fails or Issues Error 18” on page 50
- “MULTI Reports a 'Traceserv Failed to Respond' Error” on page 50
- “The Trace List Is Empty, Near Empty, or Reports an Error” on page 50

detect Issues Error 60

If the **detect** command returns the following:

```
ERROR 60: Target power off
```

1. Check to make sure that your target's power is turned on and your connections are tightly seated.

2. If your target's power is on, the probe's logic high level may be configured too low or too high for your target. See “Configuring the Probe's Logic High Level” on page 54.
3. After configuring the logic high level, run **detect** again.

detect Does Not Display a Processor Table

If the **detect** command does not display a processor table, but returns output similar to the following:

```
ERROR 1 (general error): Unable to detect target. (jtag_ir_length=0; TDO
held low?) Please use the "set target" command to configure manually.
ERROR 1 (general error): Timeout while trying to determine number
of cores.
```

The logic high level of the probe may be set incorrectly for your target. See “Configuring the Probe's Logic High Level” on page 54.

If the **detect** command continues to fail, there may be a low-level JTAG connection problem. See “Diagnosing Low-Level JTAG Connection Problems” on page 52.

detect Issues Error 71

If the **detect** command returns the following:

```
ERROR 71: probe output pins are disabled
```

look at the LEDs on the front of the probe on the right side. If they are blinking:

1. In a serial terminal, type `jp on` or press the **User** button on the front of your probe.
2. If the LEDs stop blinking, run **detect** again.
3. If you still get the same error, type `reboot`. After the probe has finished rebooting, run **detect** again.

detect Sets the Target Processors and then Issues an Error

If the **detect** command is able to set your target string but then returns an error, it is likely that the probe cannot reset the target. For more information, see “tr Does Not Reset the Target” on page 49.

detect Sets the Target Processor to other

If the **detect** command sets your target string to `other`, enter the following command in the serial terminal:

```
set target ?
```

Look for your processor in the resulting list. If your processor is listed:

1. Configure the probe's target setting manually with the following command:

```
set target target_string
```

where *target_string* is the string listed for your processor.

2. Configure the probe's endianness setting:

```
set endianness mode
```

where *mode* is either `big` or `little`.

If your processor is not listed, it may not be supported. Contact your Green Hills sales representative for more information.

detect Sets the Target Processor Incorrectly

Because multiple processors within the same family sometimes have the same PVR or `idcode`, **detect** might not set the target to the correct processor. If this happens, set your target processor manually using the instructions in “detect Sets the Target Processor to other” on page 48.

detect Passes but vb Fails

PowerPC 5xx, PowerPC 8xx, and ColdFire targets do not support the **vb** command. Do not use this command if you have one of these targets. If your target does support the **vb** command, but it fails, the error message should look similar to:

```
ERROR 13 (test failed): Test failed: in=input, out=output,  
i=iter
```

If you receive this error:

1. The JTAG clock may be set too fast. Set the clock to 1MHz by typing the following command in the serial terminal:

```
set clock 1MHz
```

If **vb** works after you decrease the clock speed, you can try increasing it slowly until you find a higher speed that works.

2. You may need to set the probe's logic high level. See “Configuring the Probe's Logic High Level” on page 54.
3. If **vb** continues to fail after you have configured the probe's clock speed and high logic level, your target processor may have been set incorrectly. For information about solving this problem, see “detect Sets the Target Processor Incorrectly” on page 48.

tr Does Not Reset the Target

If your target does not reset when you enter the **tr** command, the JTAG clock speed might not be set correctly. To adjust the clock speed:

1. In a serial terminal, type `set clock 1MHz` to set the clock speed to 1MHz.
2. Type `tr` to reset your target.

If **tr** still does not reset your target:

- The nHRESET and nTRST lines may be tied together. For more information, see “Diagnosing JTAG TAP and CPU Reset Line

Problems” in Appendix D, “Troubleshooting and Usage Notes” in the *Green Hills Debug Probes User's Guide*.

- The JTAG reset pin may be connected to an open-drain connection, meaning that your target must have a pull-up resistor in order to drive it HIGH. For more information, see “Diagnosing Low-Level JTAG Connection Problems” on page 52. If your target does have a pull-up resistor and your probe has a serial number less than 2500, try increasing the strength of the pull-up on reset.

vr Fails or Issues Error 18

If `vb` passes, but `vr` fails or returns an error such as:

```
ERROR 18: the target is not stopped
```

the JTAG clock speed may be set too high. To fix this problem:

1. In a serial terminal, type the following command to lower the clock speed:

```
set clock 1MHz
```
2. Type `vb` to confirm that you can communicate with the target. If you are using a BDM target, type `tr` instead of `vb`.
3. Type `vr 100` to perform the register test again.

MULTI Reports a 'Traceserv Failed to Respond' Error

If MULTI opens a dialog box with the message `traceserv failed to respond`, wait one minute and click the **Continue** button. When the probe boots, it performs a self test that can take up to one minute. This test must complete before the probe can begin collecting trace data.

The Trace List Is Empty, Near Empty, or Reports an Error

If the **Trace List** is empty, near empty, or reports `No Full Address Broadcast Found`, the SuperTrace Probe is probably unable to collect trace data from your target. In this case:

- If you have a trace pod or adapter, make sure that it is securely connected to the cable. Also make sure that the cable is securely connected to the SuperTrace Probe body.
- Make sure the trace pod, adapter, or High-Speed Serial Trace cable is connected securely to the connector on your board, and is in the correct orientation.
- Make sure the trace outputs are enabled on your board (see “Enabling Your Target's Trace Port” on page 54).
- Make sure the SuperTrace Probe's adapter setting is `auto`.

General Configuration Instructions

While the previous sections explained how to fix specific problems that you may encounter while configuring your probe, this section explains how to troubleshoot probe problems that are more general in nature.

- “Diagnosing Low-Level JTAG Connection Problems” on page 52
- “Configuring the Probe's Logic High Level” on page 54
- “Enabling Your Target's Trace Port” on page 54
- “Recovering that Does Not Boot Properly” on page 55
- “Uninstalling Probe Software” on page 56

Diagnosing Low-Level JTAG Connection Problems

Use the **vta** command to troubleshoot low-level JTAG connection problems. **vta** verifies that the probe can individually control each pin on the target by individually setting each pin HIGH and LOW, checking for shorts, opens, and stuck-at conditions. For example, **vta** can detect if the TCK pin is shorted to GND, or if the TMS pin is not making contact with the probe.

To run this test:

1. Unplug the ribbon cable or pod from your target in case there is a shorted pin or other problem that could cause damage.
2. In the serial terminal, type **vta**.

The results of a successful test look similar to the following output (only a few lines are shown here):

```
>vta
Testing arm-20 adapter pins:
    VTREF passed. [100%]
    VSUPPLY passed. [100%]
    NTRST passed. [100%]
    GND passed. [100%]
    TDI passed. [100%]
    GND passed. [100%]
    TMS passed. [100%]
```

If a pin has a connection problem, the probe issues an error. For example, if the probe could not bring TDO low, it would print:

```
TDO was not initially low.
```

Check that target adapter type shown in the results correctly matches the adapter on the probe's front panel. If this test fails and the adapter type is correct, there may be a problem with the adapter on the probe. In this situation:

- Repeat the test with the ribbon cable unplugged from the adapter.
- Verify that the adapter is plugged in securely, and the screws are snug.
- Remove the adapter, inspect it for damage or contaminants, re-install it, and repeat the test.

If the test still fails, the probe or target adapter may be damaged. In this situation:

- Try a different target adapter
- Try a different cable. If using an active COP pod, try a passive COP cable or a shielded COP cable.
- Contact Green Hills technical support.



Note

Some JTAG pins controlled by the probe (for example, reset lines) are connected to open-drain connections with more than one driver, meaning that the probe cannot drive them HIGH. When you run **vta** with your target unplugged, it issues the following message for each of these pins, because there is no pull-up resistor on the target adapter to bring the signal HIGH:

```
PIN could not be brought high.
```

If *PIN* is connected to an open-drain connection, this does not necessarily mean that there is a problem with the adapter, but it indicates that there should be a pull-up resistor on the target board for this pin.

Configuring the Probe's Logic High Level

To set the logic high level manually:

1. Consult your target's reference manual to confirm its logic high level.
2. If the logic high level is less than or equal to 3.3V, type the following command in the serial terminal:

```
set logic_high level
```

where *level* is the logic high level for your target. To confirm that the probe has updated this setting, type:

```
set logic_high
```

Enabling Your Target's Trace Port

In order to collect trace data, you must enable the trace port on your target. If you selected your target in the **Project Wizard**, it may have provided you with one of the following ways to enable trace:

- The generated setup script may enable trace ports by default. In this case, you do not need to do anything.
- The generated setup script may require you to set a variable in the script to enable trace. To check if this is the case, in the Project Manager, open the **Target Resources** project and double-click **mpserv_standard.mbs** to edit it.
- There may be two setup scripts, one that enables trace and one that does not. In this case, you must specify the setup script that enables trace (see the documentation about specifying setup scripts in the *MULTI: Debugging* book).
- If you are using High-Speed Serial Trace, you may need to perform additional steps. For more information, see “Additional Considerations for High-Speed Serial Trace” in Chapter 2, “Configuring Target Resources” in *Green Hills Debug Probes User's Guide*.

If you are using custom hardware, refer to your hardware's manual for information about enabling the trace port, and add the necessary commands to your setup script.

Recovering that Does Not Boot Properly

If your probe is not booting properly, you can recover it using the serial port with the instructions below:

1. Turn your probe off.
2. On your host machine, run MULTI. In the MULTI Launcher, select **Utilities → Probe Administrator**.
3. In the **Probe Administrator** window, select **Probe → Recover Probe**. A dialog box opens to confirm that you want to update your firmware. Click **OK**.
4. The **Update Probe Firmware** window opens. Enter the full path to a firmware file in the **Firmware File** box, or click the  button and select it in the file chooser. Click the **Flash Probe** button.
5. The **Serial Boot** dialog box opens. If the correct serial port is not already displayed, type the name of the serial port to which your probe is connected. Click **OK**.
6. A dialog box opens. Turn your probe on while holding down the **User** button (as instructed by the dialog). After turning on your probe, click the **OK** button.
7. The **Reloading Probe Firmware** dialog box opens and displays the status of the update. When it is finished, click **Done**.
8. Power cycle your probe. The new firmware is now loaded and running.



Note

For information about updating probe firmware, see “Updating Probe Firmware” in Chapter 1, “Administering Your Probe” in *Green Hills Debug Probes User's Guide*.

Uninstalling Probe Software

To uninstall probe software on Linux/Solaris, follow the instructions for using **gpatch** located at ***install_dir/restore/readme.txt***.

To uninstall probe software on Windows, use the **Add/Remove Programs** feature in your version of Windows.

Index

A

- adapter type, setting, 51
- Add Item to Project dialog box, 30

B

- baud rate
 - configuring, 40
 - default, 10
- build, performing, 32

C

- commands
 - detect, 22, 46, 47, 48, 49
 - dlh, 54
 - rr, 24
 - set adapter, 51
 - set baud, 40
 - set clock, 50
 - set ip, 18
 - set logic_high, 54
 - setup net, 15, 16
 - tl, 24
 - tr, 24, 49
 - vb, 24, 49
 - vle, 24
 - vr, 24, 50
 - vta, 49, 52
- compile (see build, performing)
- components, 4
- configuration
 - adapter type, 51
 - baud rate, 40
 - detecting your target, 22
 - DHCP, 15
 - gateway, 17
 - hostname, 15
 - loading from a file, 23
 - logic high level, 54
 - network mask, 17
 - static IP address, 16
 - troubleshooting, 46

- connection
 - MULTI to target, 33
 - probe to host machine
 - Ethernet, 14
 - serial terminal, 10
 - Telnet, 18
 - troubleshooting, 43
 - USB, 20
 - probe to MULTI, 21
 - testing
 - Ethernet, 18
 - trace pod, 24
- Connection Chooser, 33
- Connection Editor, 33
- core, selecting, 24

D

- debugging, 35
- detect command, 22, 46, 47, 48, 49
- DHCP, configuring, 15
- diagnostics, running, 24
- dlh command, 54
- downloading programs, 35
- drivers, installing USB, 5, 20

E

- Ethernet connection
 - setting up, 14
 - testing, 18
- example project, adding, 30

F

- firmware, recovering, 55

G

- gateway, configuring, 17

H

- hostname, configuring, 15
- HyperTerminal, 41

I

- installation
 - hardware, 7
 - Linux, 5
 - Solaris, 5
 - Windows, 5
- IP address, checking, 18

J

JTAG bypass mode, testing, 24

JTAG troubleshooting, 52

L

linker directives files

 created by Project Wizard, 28

logic high level, 54

M

MULTI

 connecting to target, 33

 Debugger, 35

 installing, 2

N

network mask, configuring, 17

P

ping, 43

Prepare Target dialog box, 35

Probe Administrator, 21

Project Manager

 configuring target hardware with, 28

Project Wizard

 testing target configuration with, 28

R

registers

 obtaining names and values of, 24

 testing reads and writes, 24

requirements, system, 2

resetting the target board, 24

rr command, 24

S

serial terminal

 baud rate, 40

 connecting to, 10

 settings for, 10

 troubleshooting, 40, 41

set adapter command, 51

set baud command, 40

set clock command, 50

set ip command, 18

set logic_high command, 54

setup net command, 15, 16

setup script, board

 specifying, 34

setup scripts

 specifying, 54

 trace, enabling, 54

setup scripts, board

 created by Project Wizard, 28

static IP address, configuring, 16

system requirements, 2

T

target

 detecting, 22

target board

 configuring, 28

 connecting to, 33

 resetting, 24

 setup script for, 34

Target Resources project, 31

Target Transition Module

 testing, 52

Telnet connection, 18

tl command, 24

Top Project

 contents, 28

 structure, 31

tr command, 24, 49

trace

 data, viewing, 36

 enabling on target, 54

 troubleshooting, 50

Trace List, 36, 50

trace pod connection, testing, 24

troubleshooting

 configuration, probe, 46

 detect command, 46, 47, 48, 49

 Ethernet connections, 43

 hardware connection, 40

 hardware setup, 38

 HyperTerminal, 41

 JTAG, 52

 overview, 38

 resetting target board, 49

 serial terminal connection, 40, 41

 Telnet connections, 43

 trace, 50

 USB connections, 45

U

USB connections, 20, 45

USB drivers, installing, 5, 20

V

vb command, 24, 49
vle command, 24
vr command, 24, 50
vta command, 49, 52

W

Windows Install New Hardware Wizard, 20

